


MCII-e *System Controller Card* *Technical Manual*



Proprietary Notice

The product information and design disclosed herein were originated by and are the property of Bosch Security Systems, Inc. Bosch reserves all patent, proprietary design, manufacturing, reproduction, use and sales rights thereto, and to any article disclosed therein, except to the extent rights are expressly granted to others.

Copyright Notice

Copyright 2012 by Bosch Security Systems, Inc. All rights reserved. Reproduction, in whole or in part, without prior written permission from Bosch is prohibited.

*All other trademarks are property of their respective owners.

Warranty and Service Information

For warranty and service information, refer to the appropriate web site below:

- RTS www.rtsintercoms.com/warranty
- RTSTW www.rtsiw.com/warranty
- AudioCom..... www.telexaudiocom.com/warranty
- RadioCom www.telexradiocom.com/warranty
- Headsets www.intercomheadsets.com/warranty

Customer Support



Technical questions should be directed to:

Customer Service Department
 Bosch Security Systems, Inc.
 12000 Portland Avenue South
 Burnsville, MN 55337 USA
 Telephone: 877-863-4169
 Fax: 800-323-0498
 Info@rtsintercoms.com

Technical Questions EMEA
 Bosch Security Systems Technical Support EMEA
http://www.rtsintercoms.com/contact_main.php

Disclaimer

The manufacturer of the equipment described herein makes no expressed or implied warranty with respect to anything contained in this manual and shall not be held liable for any implied warranties of fitness for a particular application or for any indirect, special, or consequential damages. The information contained herein is subject to change without prior notice and shall not be construed as an expressed or implied commitment on the part of the manufacturer.

 <p>THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.</p>	<p>CAUTION</p> <p>RISK OF ELECTRIC SHOCK DO NOT OPEN</p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER-SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>	 <p>THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT</p>
SEE MARKING ON BOTTOM/BACK OF PRODUCT		


WARNING: APPARATUS SHALL NOT BE EXPOSED TO DRIPPING OR SPLASHING AND NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS.

WARNING: THE MAIN POWER PLUG MUST REMAIN READILY OPERABLE

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, GROUNDING OF THE CENTER PIN OF THIS PLUG MUST BE MAINTAINED.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPRATUS TO RAIN OR MOISTURE.

WARNING: TO PREVENT INJURY, THIS APPARATUS MUST BE SECURELY ATTACHED TO THE FLOOR/WALL/RACK IN ACCORDANCE WITH THE INSTALLATION INSTRUCTIONS.

	<p>This product is AC only.</p>
---	---------------------------------

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Table of Contents

INTRODUCTION	3
Introduction	3
Features	3
Specifications	4
System Diagram	4
Reference View - Front Card	5
Reference View - Back Card	7
DIP Switches	8
Connector Pinouts	10
 CONFIGURING THE MCII-E	 13
System Requirements	13
Default Ethernet IP Addresses	14
Ethernet Setup for MCII-e System Controller	14
Set the IP Address for the MCII-e System Controller	14
Download Firmware for the MCII-e System Controller	17
Non-Base 16 Port Number Systems vs. Base 16 Port Number Systems	18
Non-Base 16 Port Number System	18
Base 16 Port Number System	21
ADAM-M Port Allocation	22
 ACCESSORIES	 23
Accessories	23
XCP-ADAM-MC Master Controller Breakout Panel	23
AZedit	24
Trunking Systems	24
UIO-256	24
PAP	24
LCP	24
GPI/O (General Purpose Input/Output)	24
 TRUNKING AND THE MCII-E SYSTEM	 25
Trunking and the MCII-e System Controller	25
Enable Trunk Support In AZedit	25
Connect The MCII-e To The Trunk Master (Data)	26
Configure The Trunkmaster To Communicate With The MCII-e System Controller Card	26
In AZedit	27
In TrunkEdit - Define the trunk line	28
In AZedit	28

Introduction

Introduction

The MCII-e System controller card is the third generation controller for the ADAM/ADAM-M Intercom System. Designed to replace the ADAM-MC, it adds a number of key features. Adding Ethernet connectivity between the ADAM/ADAM-M Intercom and the PC running AZedit, the new controller can support up to 35 simultaneous AZedit sessions (32 using Ethernet and up to three (3) using serial ports). Using a pair of MCII-e controller cards will provide full redundancy with seamless automatic change-over upon failure.

The speed of Ethernet, combined with expanded memory, allows the card to fully support large matrices with reduced setup file download time.

As with all ADAM/ADAM-M Intercom family products, the MCII-e card supports all standard, hot-swappable, and configurable features through the AZedit configuration software. It is fully compatible with existing ADAM/ADAM-M systems and cards, including AIO-8, AIO-16, AES-3, and RVON VoIP interfaces

NOTE: The new MCII-e System Controller card is only for use in the ADAM/ADAM-M Matrix Intercom System and cannot be intermixed with older ADAM master controllers in a given frame.

Features

<i>Installation:</i>	The MCII-e System Controller card is hot-swappable and installs into slots 19 or 20 in an ADAM Intercom System or slots MC1 and MC2 in an ADAM-M.
<i>Trunk Capable:</i>	The MCII-e System Controller card supports ancillary data control for use with Telex Intelligent Trunking.
<i>Ethernet Compatible:</i>	Fully Ethernet capable. The MCII-e provides a single RJ-45 connection for use with a 10BASE-TX or 100BASE-TX compliant and network. Each system controller has its own IP Address network access.
<i>AZedit Configurations:</i>	The MCII-e can connect to AZedit via Ethernet or Serial (RS-232) connections. Also, the new Intercom Sizing Wizard in AZedit makes configuring the new system controller card easier than ever.
<i>Controls:</i>	Reset button switch, general indicators, an LED module for advanced monitoring features and for gathering additional card information.

Specifications

Power

7.5W / 1.5A @ 5V

Physical

5.687" (144.45mm) W x 11.024" (280.01 mm) L

Connectors

SCSI connector via backcard

RJ-45 Ethernet via backcard

Miscellaneous

4 Mbytes of Code Flash

32MB of SDRAM

8Mbytes Configuration Flash

System Diagram




FIGURE 1. System Diagram - MCII-e Master Controller

Reference View - Front Card




FIGURE 2. MCII-e System Controller Card Board view.




FIGURE 3. LED Descriptions for the MCII-e

Reference View - Back Card




FIGURE 4. Back Card

DIP Switches

DIP Switch SE02, shown in Figure 5, is used to configure the MCII-e. Configurations include setting the baud rate and determining the Master and Slave frame in a multi-frame system.




FIGURE 5. Dip Switch SE02

TABLE 1. PCII-e Version 1.19.2 Dip Switch Settings

Dip Switch	Description
1	Debug Only! Must be in open position.
2	Sets the baud rate for the AZedit serial connection via J1. By default, AZedit is set for COM 1 and 38,400 kbps (38.4K). The baud rate set in AZedit must match the baud rate setting of the Master Controllers in ADAM/ADAM-M. Default = closed Open = 9600 Closed = 38.4k Baud
3	Reserved, keep in open position.
4	Reserved, keep in open position.
5	Reserved, keep in open position.
6	Debug Only! Must be in open position
7	Determines Master/Slave Frame in a multi-frame system. Default = closed Open = Slave Frame Closed = Master Frame
8	Debug Only! Must be in open position.

IMPORTANT: DIP Switches 1, 6, and 8 should always be left in the open position. These are reserved for debugging and can have unintended consequences if not in the open position.

TABLE 2. MCII-e Version 1.6.2 and higher Dip Switch Settings

Dip Switch	Description
1	Debug Only! Must be in open position.
2	Sets the baud rate for the AZedit serial connection via J1. By default, AZedit is set for COM 1 and 38,400 kbps (38.4K). The baud rate set in AZedit must match the baud rate setting of the Master Controllers in ADAM/ADAM-M. Default = closed Open = 9600 Closed = 38.4k Baud
3	Reserved, keep in open position.
4	Reserved, keep in open position.
5	Reserved, keep in open position.
6	Debug Only! Must be in open position
7	Reserved, keep in open position.
8	Debug Only! Must be in open position.

Connector Pinouts

AZedit #1		
68-pin Master Controller	J-1 of XCP-ADAM-MC	Assignment 2W
1	1	RS485 TX/RX-
3	2	RS232C RX
37	3	RS232C TX
4	4	RS422 TX-
2	5	Ground
2	6	Ground
38	7	RS422 TX+
35	8	RS485 TX/RX+
	9	

Trunking System		
68-pin Master Controller	J-2 of XCP-ADAM-MC	Assignment 2W
5	1	RS485 TX/RX-
36	2	Ground
6	3	RS232C RX
	4	Not Used
41	5	RS422 TX+
39	6	RS485 TX/RX+
36	7	Ground
40	8	RS232C TX
7	9	RS422 TX-

UIO-256/PAP/LCP		
68-pin Master Controller	J-3 of XCP-ADAM-MC	Assignment 2W
8	1	RS485 TX/RX-
9	2	Ground
	3	Not Used
	4	Not Used
44	5	RS422 TX+
42	6	RS485 TX/RX+
9	7	Ground
	8	Not Used
10	9	RS422 TX-

General Purpose		
68-pin Master Controller	J-4 of XCP-ADAM-MC	Assignment 2W
11	1	RS485 TX/RX-
43	2	Ground
	3	Not Used
	4	Not Used
46	5	RS422 TX+
45	6	RS485 TX/RX+
43	7	Ground
	8	Not Used
12	9	RS422 TX-

General Purpose		
68-pin Master Controller	J-5 of XCP-ADAM-MC	Assignment 2W
11	1	RS485 TX/RX-
14	2	Ground
	3	Not Used
	4	Not Used
	5	Not Used
47	6	RS485 TX/RX+
14	7	Ground
	8	Not Used
	9	Not Used

General Purpose / Bus Exp.		
68-pin Master Controller	J-6 of XCP-ADAM-MC	Assignment 2W
15	1	RS485 TX/RX-
48	2	Ground
	3	Not Used
	4	Not Used
	5	Not Used
49	6	RS485 TX/RX+
48	7	Ground
	8	Not Used
	9	Not Used

General Purpose / Bus Exp.		
68-pin Master Controller	J-7 of XCP-ADAM-MC	Assignment 2W
16	1	RS485 TX/RX-
17	2	Ground
	3	Not Used
	4	Not Used
	5	Not Used
50	6	RS485 TX/RX+
17	7	Ground
	8	Not Used
	9	Not Used

AZedit #3		
68-pin Master Controller	J-10 of XCP-ADAM-MC	Assignment 2W
	1	Not Used
67	2	Ground
21	3	RS232C RX
	4	Not Used
	5	Not Used
	6	Not Used
67	7	Ground
54	8	RS232C TX
	9	Not Used

General Purpose / Bus Exp.		
68-pin Master Controller	J-8 of XCP-ADAM-MC	Assignment 2W
18	1	RS485 TX/RX-
51	2	Ground
	3	Not Used
	4	Not Used
	5	Not Used
52	6	RS485 TX/RX+
51	7	Ground
	8	Not Used
	9	Not Used

AZedit #2		
68-pin Master Controller	J-9 of XCP-ADAM-MC	Assignment 2W
	1	Not Used
19	2	Ground
20	3	RS232C RX
	4	Not Used
	5	Not Used
	6	Not Used
19	7	Ground
53	8	RS232C TX
	9	Not Used

General Purpose			
68-pin Master Controller	J-11 of XCP-ADAM-MC	Assignment	Signal
22	1	MI (0)	Logical Input (0)
23	2	MI (1)	Logical Input (1)
24	3	MI (2)	Logical Input (2)
25	4	MI (3)	Logical Input (3)
26	5	MI (4)	Logical Input (4)
27	6	MI (5)	Logical Input (5)
28	7	MI (6)	Logical Input (6)
29	8	MI (7)	Logical Input (7)
30	9	Ground	Ground
31	10	Ground	Ground
32	11	Ground	Ground
33	12	Ground	Ground
34	13	Ground	Ground
55	14	MO (0)	Logical Output (0)
56	15	MO (1)	Logical Output (1)
57	16	MO (2)	Logical Output (2)
58	17	MO (3)	Logical Output (3)
59	18	MO (4)	Logical Output (4)
60	19	MO (5)	Logical Output (5)
61	20	MO (6)	Logical Output (6)
62	21	MO (7)	Logical Output (7)
63	22	Ground	Ground
64	23	Ground	Ground
65	24	Ground	Ground
66	25	Ground	Ground

Configuring the MCII-e

System Requirements

IMPORTANT:

If you are using:

- A single, frame system, you must be using MCII-e version 1.6.2 or later.
- A multi-frame system with DBX cards, you must be using PCII-e version 1.19.2 or later.
- A multi-frame system with Tribus cards, you must be using MCII-e version 2.0.2 or later.

Before you configure your MCII-e System Controller card, verify the following items are updated:

- AZedit v 2.08.01 or later
- AIO-8 v 10.3.4 or later
- AIO-16 v 1.0.0 or later
- Periph-IIe, requires DBX v1.14.0 or later

NOTE: Field upgrade of DBX requires Boot Code upgrade to version 0.0.3. If the Boot Code is not upgraded, the DBX card will not work with the MCII-e.

Default Ethernet IP Addresses

Product	Default IP Address	Default Subnet Address
RVON-I/O	192.168.0.1	255.255.0.0
RVON-8	192.168.0.2	255.255.0.0
RVON-1& RVON-2	192.168.0.3	255.255.0.0
RVON-C	192.168.0.4	255.255.0.0
RVON-16	192.168.0.5	255.255.0.0
GPIO-16	192.168.0.6	255.255.0.0
MCII-e	192.168.0.7	255.255.0.0
Cronus	192.168.0.8	255.255.0.0
Zeus III	192.168.0.9	255.255.0.0

Ethernet Setup for MCII-e System Controller

Set the IP Address for the MCII-e System Controller

NOTE: The PC must be running version 2.08.01 or later of AZedit and have an Ethernet card installed. The MCII-e can support up to 32 concurrent sessions of AZedit on Ethernet.

Verify the MCII-e is connected to the PC using a RS-232 (ADAM/ADAM-M standard) cable. Connect J1 on the XCP-ADAM-MC to the COM port on the PC.

NOTE: For more information on Network Basics, see the Basic Networking Guide found at <http://www.telex.com/Intercoms/files.nsf/sitemap#Brochures>, under *Applications*.

If there are two (2) controllers, they must each have their own unique IP Addresses (different from each other and any other devices sharing the same network).

To **connect the Active MCII-e to the PC with a serial cable**, do the following:

1. Open **AZedit**.
The Keypanels/Ports screen appears.
2. From the Option menu, select **Ethernet Setup**.
The Ethernet Setup screen appears.

3. In the IP Address field, enter the **IP Address** for the current MCII-e System Controller.
4. In the Network Mask field, enter the **Network Mask** number for the current MCII-e System Controller.
5. Where appropriate, in the Default Gateway field, enter the **Gateway** number for the MCII-e System Controller.

NOTE: If the MCII-e communicates with hosts outside its network, enter the IP address of a host or router which will serve as the **Gateway**. Otherwise, if the MCII-e only needs to communicate with the local network, leave the Default Gateway field at its default setting (0.0.0.0).

The Default Gateway is normally configured the same on both the active and standby MC-II-e System Controller Cards.

The same screen you use to set the network settings can be used to view the settings as well. You must be connected using a serial connection via J1 to make changes, but you can view them with any type of AZedit connection (J1, J9, J10, or Ethernet).

6. Click **Apply**.
7. Click **Close**.
The Ethernet Setup window is closed.
8. Connect the **MCII-e System Controller** to your network with an Ethernet cable.

NOTE: The unique Ethernet MAC address assigned to each MCII-e card during manufacturing is displayed in the field MAC Address. It is NOT possible to modify this address.


9. Connect the **PC** to your network with an Ethernet cable.


NOTE: If you do not know these numbers, your system administrator can supply the IP Address and Netmask to use.

To **configure the communication settings**, do the following:


1. From the Options menu, select **Communications**.

The Communication screen appears



2. In the Connection area, select the **Network** radio button.
3. In the IP Address field, either enter the **MCII-e IP Address** you wish to connect with, or click the **Search** button. 

The search button scans the network for any MCII-e devices. If multiple units are on the network, each will appear in the list.



4. Select the **MCII-e System Controller** you wish to work with.
5. Click **OK**.

The Communications screen closes. The IP Address is configured in AZedit for the MCII-e System Controller.

Download Firmware for the MCII-e System Controller

CAUTION: The following procedure will cause one or more brief disruptions in intercom communications. Also, **SAVE** your intercom system configuration. From the File menu, select **SAVE**. Later, if you need to restore the intercom configuration from disk, use *Send File* in the *Online Menu*.

IMPORTANT: Before you begin, be sure to verify that **SERVER** mode has been disabled. Also, it is extremely important to take the Standby Controller card out of the frame, if one is installed.

NOTE: The Active Master Controller has the topmost red LED (#23) on in the status window.

To **download master controller firmware**, do the following:

1. From the Status Menu, select **Software Versions**.
A popup list appears.
2. From the Software Versions popup list, select **Master Controllers**.
The Master Controller Version Information screen appears.
3. Right-click the active Master Controller, and then select **Download Firmware**.
The Firmware Download screen appears.

NOTE: You can also press **Ctrl+Shift+D** to open the Firmware Download screen once the Master Controller is highlighted.

4. From the Firmware Download screen, select the **firmware update file**.
Or
Use the **browse** button to navigate where the new file resides.
5. Click **Open**.
The firmware update appears in the Download Firmware screen.
6. Click **Begin Download**.
This process can take as little as 30 seconds with "Fast Ethernet" or as long as five minutes when using a serial connection at 9600 baud.

NOTE: If there is any disruption in the communication link during the download, you will get an error message. In this case, repeat the download.

When the file has been completely downloaded, the MCII-e System Controller will begin processing the update.

IMPORTANT: Any disruption at this point, such as loss of power, removing or resetting cards may result in Master Controller failure. If this happens, you will have to return the affected unit for replacement or repair.

The AZedit session goes offline for 15-20 seconds when the card performs a reset. It automatically reconnects when finished.

When the Master Controller is finished, the new software version will appear in the version field of the Version Status screen.

If you do not have a Standby Master Controller card, you can skip steps eight and nine.

7. Once the Active Master Controller is updated, remove **the Master Controller** from the frame.
8. Insert the Standby Master Controller and repeat **steps 3 through 8**.
9. When the Standby Master Controller is finished, insert **both controllers and resend your system setup file**.

Non-Base 16 Port Number Systems vs. Base 16 Port Number Systems

With the advent of the TBX-Tribus card and the ever-evolving technology to a 16-channel port system, **Non-Base 16** (or standard density) and **Base 16** (or high density) port number systems were created.

NOTE: Any 16-channel card, must use the high density (Base 16) port numbering system. Alternatively, any 8-channel card can use either the standard density (Base-8) or high density (Base 16) port numbering system

Non-Base 16 Port Number System

The **Non-Base 16 Port Number System** splits 16 ports between a top and bottom group. The bottom group starts with 1 through 136; the top group consists of ports 137 through 272 (see Figure 6).

EXAMPLE: This means that if you have an AIO-16 in slot 1, ports 1–8 and 137–144 is used by the AIO-16 card. Alternatively, if you have AIO-16’s in slots 1 and 3 and an AIO-8 in slot 2, the following port mapping applies:

Figure 3. Example for Base 8 Port Numbering

AIO-16 Ports 1– 8 and 137–144	Ports 145-161 are not used when an AIO-8 card is in the slot	AIO-16 Ports 17–33 and 162–178
	AIO-8 Ports 9–16	
Slot 1	Slot 2	Slot 3




FIGURE 6. Non-Base 16 Port Numbering System Example




FIGURE 7. Non-Base 16 Port Numbering scheme with both AIO-16 and an AIO-8 card installed.

Base 16 Port Number System

The **Base 16 Port Number System** is newly supported with the TBX-Tribus Card. Unlike the Base 8 Port Number System, where the ports were split into an upper and lower set of eight (8) ports, the Base 16 Port Number System puts all 16 ports in one slot. This means, when you configure your intercom system to support Base 16, slot 1 in the ADAM holds ports 1 through 16, slot 2 holds ports 17 through 33, slot 3 holds 34 through 49, and so on. When a Tribus card is inserted into the frame, the port numbering system jumps to the next available AIO card slot, see Figure 8.




FIGURE 8. Base 16 Port Numbering System Example

ADAM-M Port Allocation

16 ports (81-96)	SLOT 6		
16 ports (65-80)	SLOT 5		
16 ports (49-64)	SLOT 4	16 ports (113-128)	SLOT 8
16 ports (33-48)	SLOT 3	16 ports (97-112)	SLOT 7
16 ports (17-32)	SLOT 2	MCII-e Master Controller	
16 ports (1-16)	SLOT 1	MCII-e Master Controller	

Straight Base 16 Configuration
using an ADAM-M

Tribus Card	SLOT 6		
16 ports (65-81)	SLOT 5		
16 ports (49-64)	SLOT 4	16 ports (98-113)	SLOT 8
16 ports (33-48)	SLOT 3	16 ports (82-97)	SLOT 7
16 ports (17-32)	SLOT 2	MCII-e Master Controller	
16 ports (1-16)	SLOT 1	MCII-e Master Controller	

Base 16 Configuration with one (1) Tribus
using an ADAM-M

8 ports (41-48)	SLOT 6	8 ports (105-112)			
8 ports (33-40)	SLOT 5	8 ports (97-104)			
8 ports (25-32)	SLOT 4	8 ports (89-96)	8 ports (57-64)	SLOT 8	8 ports (121-128)
8 ports (17-24)	SLOT 3	8 ports (81-88)	8 ports (49-56)	SLOT 7	8 ports (113-120)
8 ports (9-16)	SLOT 2	8 ports (73-80)	MCII-e Master Controller		
8 ports (1-8)	SLOT 1	8 ports (65-72)	MCII-e Master Controller		
Bottom		Top	Bottom		Top

Non-Base 16 Configuration
using an ADAM-M

FIGURE 9.


Accessories

FIGURE 10. Connection Diagram. The 68-pin SCSI can be attached to the XCP-ADAM-MC.

NOTE: AZedit sessions are only enabled on J9 or J10 when the advanced communication boxes are enabled from “communications” screen and the correct baud rates are configured.

XCP-ADAM-MC Master Controller Breakout Panel

The **XCP-ADAM-MC Breakout Panel** allows many different peripherals to be connected to the master controller of an ADAM Intercom System, such as AZedit, trunking systems, UIOs, PAPs, LCPs, GPI/Os, etc. For the breakout panel pinouts, see pages 9-15.

AZedit

AZedit is a Windows-based, full-featured configuration software, providing online and offline configuration capabilities. It gives you the ability to manage multiple intercom systems, assign and reassign users to different ports, as well as dynamically add hardware to your system setup without jumper changes, rewiring, or taking the system offline. AZedit has the capability to load pre-set configuration files, which means configurations saved to a disk can be uploaded to the “live” application at anytime, without interruption.

The XCP-ADAM-MC breakout panel has three DB-9 connectors that can be used to connect to AZedit (AZedit #1, #2, and #3).

Trunking Systems

The RTS **Trunking System** manages intercommunications between separate intercom systems using intercom ports that have been reserved and interconnected between the intercom systems with devices in other frames. Keypanels or other data devices can then communicate with devices in other frames.

UIO-256

Each **UIO-256** provides 16 GPI inputs and 16 GPI outputs. The GPI inputs can be used just like keypanel keys to activate intercom ports, party lines, relays, etc. Each relay output provides a choice of normal open and normal closed contacts. The relays can be assigned for activation from keypanel keys, and can be used to control lighting, or to key remote transmitters, paging systems, etc.

PAP

The **PAP** panel (Program Assist Panels) provides a fast and easy method of selecting any of several program sources (connected to input ports of the intercom system) for use with the IFB outputs feature of the intercom system.

LCP

The **LCP** panel (Level Control Panel) combines the functionality of three (3) products into one (1). The LCP allows you to adjust analog input and output gains, assign sources to IFB outputs and make changes on the fly, and to add members to a party line on the fly.

GPI/O (General Purpose Input/Output)

J11 provides 8 general purpose control inputs and 8 general purpose control outputs. The control inputs can be used just like keypanel keys to activate intercom ports, party lines, relays, etc. The control outputs are open-collector, active-low outputs. They can be activated by keypanel keys and can be used to control lighting, to key a remote transmitter, to activate a paging system, etc.

Pinouts for the digital inputs and outputs are summarized in “Connector Pinouts” on page 10.

Trunking and the MCII-e System

Trunking and the MCII-e System Controller

Trunking allows one intercom system to communicate with another remote intercom system with devices in other frames. For example, a user in New York can talk to a user in Los Angeles if the systems they are using are trunked together. Trunking can be configured to work with cables, fiber optics, voice over internet protocol, or any form of audio/data transfer media, to allow communication between systems.

Enable Trunk Support In AZedit

To **trunk the MCII-e System Controller Card**, do the following:

1. From the AZedit main menu, select **Options**.
The Options sub-menu appears.
2. From the Options sub-menu, select **Preferences**.
The Applications Preferences screen appears.
3. On the Applications Preferences screen, click the **Advanced** tab.
The Advanced screen appear.
4. On the Advanced screen, select **Enable trunking support**.
5. Click **OK** to save the change and close the screen. Or, click **Apply** to save the change and leave the screen open.

When your system has limited bandwidth, you want to set the Allow for Remote Trunk Master. By setting this option, the baud rate is changed to 9600 baud, instead of the default, 38.4K.

To **enable the Remote Trunk Master**, do the following:

WARNING: Enabling this option causes the system to reset. All data is erased in the frame. Be sure to save your system setup to disk before performing this task.

1. Remove the **Standby Master Controller**.
 2. From the AZedit main menu, select **Options**.
The Options sub-menu appears.
 3. From the Options sub-menu, select **Intercom Configuration**.
The Intercom Configuration screen appears.
 4. On the Intercom Configuration screen, click the **Options** tab.
The Options screen appears.
 5. On the Options screen, select **Allow for remote trunk master**.
-

6. Click **Test** to verify the intercom will accept the new settings.
7. Click **Apply**.
The intercom will stop communicating with AZedit, reconfigure itself, and then reset.
8. Resend the **current setup**.
9. Replace the **standby controller**.
It will automatically reconfigure itself to match the new settings.

Connect The MCII-e To The Trunk Master (Data)

To connect MCII-e to the Trunk Master, do the following:

- > Connect the **MCII-e System Controller Card data connector** to one of the **eight DB-9 connections** on the ICP-2000.

Configure The Trunkmaster To Communicate With The MCII-e System Controller Card

To setup the TrunkMaster to be able to communicate with MCII-e, do the following:


1. Open **TrunkEdit**.
2. In the left navigation, open the **Intercom slide screen**.
The Intercom navigation panel displays.

Icom #	Name 4	Name 6	Name 8	Baud Rate	COM Port	OK?	Cur	New	Type	Size	Status
4	CRON	CRON	CRON	38.4K	4	-	-	-	?	128	Lost contact
1	INT1	INT1	INT1	38.4K	1	Y	Y	Y	ADAM-CS	64	Up to date
2	INT2	INT2	INT2	38.4K	2	Y	Y	Y	ADAM	256	Up to date
3				9600	3	-	-	-	-	-	No communication
5				38.4K	5	-	-	-	-	-	No communication
6				38.4K	6	-	-	-	-	-	No communication
7				38.4K	7	-	-	-	-	-	No communication
8				38.4K	8	-	-	-	-	-	No communication
9				38.4K		-	-	-	-	-	No communication
10				38.4K		-	-	-	-	-	No communication
11				38.4K		-	-	-	-	-	No communication
12				38.4K		-	-	-	-	-	No communication
13				38.4K		-	-	-	-	-	No communication
14				38.4K		-	-	-	-	-	No communication

3. From the Intercom navigation, select **Setup**.
The Intercom Setup screen appears.
4. In the Intercom Setup screen, enter the **Intercom System Name (i.e.; ADAM)** in the appropriate ICOM port (for example, if the MCII-e System Controller is cabled to the ICP-2000's J4 connector, then in the Intercom Setup screen, enter the MCII-e's machine name in the line which corresponds with the COM port #4 field).
5. Select the Baud Rate field and enter the **baud rate** to match the baud setting of the Intercom Trunking port (38.4K or 9600).
6. When you are finished, click the **Send** button to send the changes to the Trunk Master. When the changes are sent to the Trunk Master, the MCII-e connects to the Trunk Master and uploads the remote ports. Once the MCII-e has uploaded this data, it sends its port alphas to the Trunk Master.

In AZedit

1. Open **AZedit**.
2. On the main screen, select the **port** you want to make available remotely.



3. In the Scroll Enable field, select **Trunk** and **AZedit**.
By enabling Trunk and AZedit on this port, remote users will display in AZedit and remote keypanel users will be able to see enabled ports.

NOTE: We recommend that you only enable user positions that will be used by remote systems.

4. Send the **changes** to AZedit.

In TrunkEdit - Define the trunk line

NOTE: We recommend you map your system before defining the trunk lines.

Defining the trunk line shows where a trunk line begins and ends, as well as shows the audio connections between frames.




Figure 4. Trunk Definition Window

To **define trunk lines**, do the following:

1. Open **TrunkEdit**.
2. In the left navigation, open the **Trunk slide screen**.
The Trunk Definitions for: All Intercoms panel displays.
3. In the ICOM 1 field, enter the **intercom name of one end** of the trunk connection (i.e.; ADAM).
4. In the Port Field, enter the **port number** where ICOM1 is assigned (i.e.; N014). Or, in the Alpha field, enter the **Alpha** of the ICOM1 system (i.e.; N014).
5. In the ICOM2 field, enter the **name of the system** ICOM1 is linked to (i.e.; INT1).
6. In the Port field, enter the **port number** where ICOM2 is assigned (i.e.; N005). Or, in the Alpha field, enter the **alpha** of the ICOM2 system.
7. Once finished with all your definitions, **Send** the changes to the TrunkMaster.

In AZedit

Once you are finished defining the trunk lines of your system, you can use AZedit to make key assignments for the keypanels. With Trunking enabled, you will be able to see all trunked system and their ports enabled in AZedit.

Bosch Security Systems, Inc.

12000 Portland Avenue South
Burnsville, MN 55337 U.S.A.
www.boschcommunications.com