RTS

Innovating the Future of Global Communications

Modular Series (MH) Headsets and Headphones User Instructions

Models Include:

MH-300
MH-300L
MH-302
MH-302L
MH-402
MH-402L

Available MH Series Accessories

Ear Cushion	F01U149725
Dynamic Microphone Windscreen	F01U149727
Headband Pad	F01U149729
Battery	F01U149731
Battery Charger North America	F01U149733
World Power Supply Adapters	F01U149735
Aux Audio Input Module	F01U149737
Single-Sided Passive Headset Frame Assembly	F01U149739
Double-Sided Passive Headset Frame Assembly	F01U149741
Analog ANR Headset Frame Assembly	F01U149743
Dynamic Microphone Module, Quick Disconnect Connector	F01U149745
Cable, Quick Disconnect to A4M Connector	F01U149747
Cable, Quick Disconnect to A4F Connector	F01U149749
Cable, Quick Disconnect to A5M Connector	F01U149751
Cable, Quick Disconnect to A5F Connector	F01U149753
Cable, Quick Disconnect to Pigtail	F01U149755
Filler Module	F01U149757
Temple Pad	F01U149759
Carrying Case	F01U149761
Dynamic Microphone Module, A4M Connector	F01U167564
Dynamic Microphone Module, A4F Connector	F01U167565
Dynamic Microphone Module, A5M Connector	F01U167566
Dynamic Microphone Module, A5F Connector	F01U167567
Dynamic Microphone Module, Pigtail	F01U167568
Headpad, 3-piece	F01U217632

List of Figures

FIGURE 1. Models MH-300 and MH-300L 5
FIGURE 2. Models MH-302, MH-302L, MH-402, and MH-402L 6
FIGURE 3. Battery Charger Reference Diagram 7
FIGURE 4. Standard Power Supply and Plug Adapters 7
FIGURE 5. ANR Switch 14
FIGURE 6. MH-402/402L in Carrying Case 19
FIGURE 7. Battery Charger Reference Diagram 22
FIGURE 8. 4-Pin XLR Connector Female and Male 25
FIGURE 9. 5-Pin XLR Connector Female and Male 26
FIGURE 10. Quick Disconnect Connector 27